



KTM

2007 SX, 2008-2016 All Models (excludes 2016 SXF / XCF models)

HUSABERG

2009 - 2014 All Models

HUSQVARNA

2014 - 2016 All Models

Mounting:

1. Remove radiator shrouds.
2. Remove OEM radiator guards.
3. Remove the (2) radiator mounting screws (save to reuse in step 4).
4. Slide guard in place, pivoting from inside to outside. Outside mounting holes should line up with existing clearance holes for plastic shrouds. Install radiator mounting screws from step 3 here.
5. Install supplied M6x25mm inside mounting through clearance hole in guard (1/4" drive swivel socket works well for this).
6. Tighten the outside bolts. Do not over tighten these bolts.
7. Turn steering to check fork tube clearance.
8. Shrouds can be installed using stock bolt or supplied strap as shown.

Note: These guards are designs and built for precision fit to maintain radiator integrity. If the radiators are already bent the guards my not fit correctly.

